# **DuPont - Cyrel** ®

**Cyrel** ® 1000 P / 2000 P / 3000 P



Pre Installation MANUAL

# **Contents**

1. Ab	out the machine		Page
1.1	Address of manufacturer	Service Manual	4
1.2	Type of equipment	Service Manual	4
1.3	Description of operation	Service Manual	5
1.4	Description of the process	Service Manual	6
1.5	Designation of jobs	Service Manual	6
1.6	Data on noise emissions		4
1.7	Information on ventilation and fumes		4
1.8	Electrical fittings	Service Manual	7
1.9	Information specific to machinery materials	Service Manual	7
2. Tr	ansporting and setting up the machine		
2.1	Unloading		5
2.2	Transporting		5
2.3	Setting up and aligning		5
2.4	Foundations		5
3. Br	inging the machine into service		
3.1	Requirements for fixing and anchoring		6
3.2	Conditions for installation		6
3.3	Space requirement for operation, servicing and maintena	nce	6
3.4	Permissible ambient conditions		6
3.5	Connecting to the power supply,		
	preparation for putting into operation, first filling		7
3.6	Principles for putting into service	Service Manual	11
3.7	Checking for correct operation	Service Manual	11/12
3.8	Requirements for use in a potentially		
	explosive atmosphere	Service Manual	12
4. Sa	fety		
4.1	Safety measures when working at the machine	Service Manual	13
4.2	Notes on the use of personal protective equipment	Service Manual	13
4.3	Information on residue risks, avoiding hazards	Service Manual	13
4.4	Environmental protection	Service Manual	13

5. Inf	ormation on the operation on the machine		
5.1	Description of the functions of all individual components	Service Manual	14-16
5.2	Measuring solid matter content and solvent heating	Service Manual	17
5.3	Description of adjustment and replacement work	Adjustments	3
5.4	Basic information about the washing brushes	Adjustments	4-7
5.5	Improper usage	Service Manual	17
5.6	Instructions for recognizing and eliminating errors	Service Manual	18
6. Op	peration		
6.1	Starting the machine	Service Manual	19
6.2	The operations field	Service Manual	19-27
6.3	Manually filling the internal tank	Service Manual	28
6.4	Plate production	Service Manual	29
6.5	"Drum-to-drum" operation	Service Manual	30
6.6	"Tank-to-tank" operation (with distillation)	Service Manual	30
7. Ins	structions for equipment maintenance		
7.1	Type and frequency of inspections (operator)	Service Manual	31
7.2	Instructions for maintenance work	Service Manual	31
7.3	Type and frequency of maintenance work (service) Service	e Manual 32	
7.4	Address of DuPont	Service Manual	33
8. Sa	fety-related information for removing the mac	hine	
fro	m service and dismantling	Service Manual	33
9. Inf	ormation for emergency situations		
9.1	Type of fire extinguishing equipment to be used	Service Manual	34
9.2	Notes for rescue	Service Manual	34
10. T	echnical data and plans		
	Delivery list		8
	Loading plan / Pre-loading plan		9/10
	Set-up plan, space requirements – transport plan		11
	Specifications, technical data		12
	Flow plan / Liquid conduits and switching points		
	for the level gauges	Service Manual	40
	Pneumatics plan	Service Manual	41
	Electrical wiring plan	Service Manual	42-55

#### 1.6 Data on noise emissions

Noise emissions < 70 db(A)

#### 1.7 Information on ventilation and fumes

Permissible workplace concentrations:

- Perchlorethylene: 50 ppm (MAK)

- FLEXOSOL: 300 ppm (OEL)

Adequate ventilation of the production room must be provided.

#### Attention:

The room air must be ventilated out from floor level because the solvent fumes can be heavier than air (depending on solvent, i.e. when using Per).

1000 P / 2000 P / 3000 P

The cleaning solution poses a threat to the water supply and must not reach the sewage system or get into the ground! A safety collection tank must be set up that can take up the entire volume of solvent (standard equipment).

The floor of the production room must be even.

In addition, the floor must be sealed with a water-repellent coating that must also be resistant to the solvent used.

Any available floor drainage must not be connected to the sewer system.

The machine's suction ventilation is located at plate input and at plate output. The exhaust line for the ventilator may not be longer than 10 m with a maximum of 2-3 / 90° bends

For exhaust lines more than 10 m in length, an additional blower must be added. This must create light low pressure at the machine ventilation points. Performance at full operation is to be set to ca. 200 m³/h with the aid of an adjustable damper.

## 2. Transporting and setting up the machine

The unloading as well as the transport of the machine may only be carried out by authorized specialists. For this work, personal protective equipment i.e. safety shoes and leather gloves are to be used!

## 2.1 Unloading

The machine is basically delivered on a palette (or packed for oversees shipping) and should be unloaded from the truck complete with packing.

When unloading the machine from the palette, be sure to lift the machine only from the bottom of the frame at the marked points and make sure no parts become damaged. The side and top sheet metal of the machine must be removed first. The machine is anchored to the cross beams with 6 fastening bolts (tool: socket wrench SW17). The output (only 2000 P and 3000 P) is secured with straps. These must also be removed.

Lift the machine with a forklift (2.2 meter fork length) and screw in the feet. Here, clearance of 110 mm must be maintained, as the safety tank (100 mm) must still be placed under the machine.

(cf. Set-up plan, space requirement – transport plan)

(cf. Loading plan)

(cf. Pre-loading plan)

## 2.2 Transporting

Unloading the machine at its final location should carried out with the appropriate means of transport, carefully and without warping. At this point, transport paths, door widths and the swinging radius are to be taken into account. (cf. Set-up plan, space requirement – transport plan)

Should space circumstances not allow transport of the complete machine, it is possible to dismantle the output (cf. Set-up: assembly / dismantling instructions for the output). These tasks must be carried out by trained personnel.

## 2.3 Setting up and aligning

When setting up the machine, there must be sufficient space between it and the walls and other machines to allow for service and maintenance work. The distance should be about 1 m.

(cf. Set-up plan, space requirement – transport plan)

At the point of set-up, the machine is to be aligned precisely with a spirit-level. For this, the cover of the washout area must be removed. The spirit-level is laid on the top edge of the tank and the machine is aligned exactly with the aid of the adjustable feet.

For installation of the safety tank, a distance of 110 to 115 mm, floor – bottom edge of the frame, is to be observed.

#### 2.4 Foundation

A special foundation for the machine is not required. The load bearing capacity of the floor should be 1000 kg/m². The weight of the machine is taken from the specification tables.

# 3. Bringing the machine into service

## 3.1 Requirements for fixing and anchoring

The machine rests on it's levelling feet; a special fixture is not required

#### 3.2 Conditions for installation

The floor of the production room must be even.

Furthermore, the floor must be sealed with a water-repellent coating that must also be resistant to the solvent used.

1000 P / 2000 P / 3000 P

Any existing floor drainage systems must not connect to the waste water system.

### 3.3 Space requirements for operation, service and maintenance

Feeding and removing plates takes place at either end of the machine. In order to allow for service work, there must be at least 1 m of free space surrounding the machine. (cf. Set-up plan, space requirements – transport plan)

#### 3.4 Permissible ambient conditions

The environment should be similar to that in an office.

Recommended room lighting: Lumilux Interna W 31 - OSRAM

Natural light UVA screened Room temperature: 22°C Relative humidity: ca.55%

## 3.5 Connecting to the power supply; Preparation for putting into operation, first filling

1000 P / 2000 P / 3000 P

#### **Electrical connection**

(recommendation)

Connect the machine through a wall switch or fuse switch.(lockable)

Follow connection terms of local power companies and all local codes.

#### Compressed air connection

dry, 6 bar / 200 l/min – via DIN, ½" hose connection.

#### Machine ventilation

The ventilation line must correspond to the dia (100 mm) of the exhaust flange. It must be installed so that the ventilation opening terminates well outdoors and outside of the workrooms. Continuing ducts can consist of galvanized steel tubing or a suitable synthetic tubing.

Exhaust ducts appropriate for the machine ventilation volume (ca. 200 m³/h) should be installed. Installing an adjustable damper is recommended.

#### Solvent supply connection

The standard version of the machine is suitable for "drum-to-drum" operation.

Here, fresh solvent appropriate for the size of the plate is supplied to the system from a drum. The saturated dirty solvent is pumped off into an empty drum.

Delivery of the standard version of the machine contains one level switch each for the fresh and for the used solvent drums (200 I). The level switches are to be put into the top side of the respective drums. The longer level switch is used for the fresh solvent drum; the shorter one for the used solvent drum. The switches will be labeled accordingly.

For connecting the line from drum to processor, connection points are provided on the back side of the machine. The other ends of the line are to be fitted into the second opening on the top side of the drums.

#### Attention

Be sure that the connecting lines are not longer than 10 m and that they lie in one plane. For security reasons, the entire length of the line must be visible.

As material for the connecting tubes, gasoline- and oil-tight tubing will be used. (- independent of

As an alternative to this, sturdy tubing can also be used. This must be equipped with a flexible connector at the corresponding drum side.

If the machine is operated with permanently installed tanks, special level switches are to be fitted for the tanks.

(Ex- or intrinsically safe level gauge in Ex-Rooms)

Should installation circumstances differ, please consult with the manufacturer or seller


# **Delivery list**

No.: .....


Pieces	Name	Control	
3	Safety drip tray		
3	Transport bar		
1	Cooling device		
2	Synthetic hose NW 13 (1/2") 0.6 + 0.8 m		
	for cooling device		
1	Air hose ø 9mm, L= 3m		
2	Filter screen		
1	Float switch for fresh solvent drum		
1	Float switch for old solvent drum		
1	Synthetic hose NW 13 (1/2") 5 m		
	for fresh and old solvent drums (fitted on site)		ļ
1	Fitting fresh solvent drum		
1	Fitting old solvent drum		
1	Exhaust tubing ø 100 mm, L= 5m		
2	Tubing clamps ø 120mm		
8	Tubing clamps ø 20-25mm		
6/8	Adjustable feet (1000 P = 6 pieces / 2000 P + 3000 P = 8 pieces)		
1	Package of filter socks		
1	Panel key		
1	Electric box key		
1	Operating instructions		
1	Wiring diagram (in control panel)		
1	Grease		
4	Tubing 1/2" (sealed with Teflon band in the machine)		
2	Tubing 1/2" loose		

1000 P / 2000 P / 3000 P


# Loading plan



# **Pre-loading plan**



# Installation plan, space requirements – transport plan



# **Specifications**

	1000 P	2000 P	3000 P
max. plate width	920 mm	1,070 mm	1,320 mm
min. plate width	200 mm	200 mm	200 mm
max. plate length	1,600 mm	2,000 mm	2,250 mm
fresh solvent tank	17 Liters	19 Liters	23 Liters
min. volume for operation	70 Liters	70 Liters	90 Liters
max. working volume	90 Liters	90 Liters	115 Liters
max. tank volume	115 Liters	115 Liters	150 Liters
net weight of machine	950 Kg	1,050 Kg	1,320 Kg
weight with palette	1,180 Kg	1,280 Kg	1,450 Kg
weight with overseas container	1,400 Kg	1,500 Kg	1,770 Kg
dimensions of palette and	4,450 mm	4,450 mm	4,700 mm
overseas container (L x W x H)	2,040 mm	2,040 mm	2,300 mm
	1,580 mm	1,580 mm	1,580 mm
color	RAL 7035	RAL 7035	RAL 7035

